



TSL ASCII PROTOCOL 2.4

[www.tsl.com](http://www tsl com)

Design • Development • Manufacture

CONTENT

Introduction.....	5
Commands Overview.....	6
Command Parser.....	7
Responses.....	8
Response field headers.....	9
AB: Autorun file Begin.....	9
AC: Authentication Chip test.....	9
AE: Autorun file End.....	9
AS: Antenna Serial number.....	9
BA: <i>Bluetooth®</i> Address.....	10
BC: Barcode data.....	10
BP: Battery Percentage level.....	10
BR: Barcode Raw.....	11
CH: Charge Status.....	11
CR: Transponder EPC CRC value.....	11
CS: Command Started.....	11
DA: Date.....	12
DP: Double press user defined switch action.....	12
DT: Date/Time Stamp.....	12
EA: Transponder Access Error Code.....	13
EB: Transponder Backscatter Error Code.....	13
EP: Transponder EPC value.....	14
ER: Error.....	14
FN: <i>Bluetooth®</i> Friendly Name.....	15
IA: UHF API Version.....	15
IX: Index Number.....	15
KS: Kill Success.....	15
LB: Log Begin.....	16
LE: Log End.....	16
LL: Log Length.....	16
LK: Licence Key.....	16
LS: Lock Success.....	17
ME: Message.....	17
MF: Manufacturer name.....	17
OK: OK response.....	17
QT: QT Control Word.....	18
PC: Transponder EPC PC value.....	18
PR: Parameters.....	18
PV: Protocol Version number.....	18
RB: Radio Bootloader version number.....	19
RD: Transponder Read Data.....	19
RF: Radio Firmware version number.....	19
RI: Transponder RSSI value.....	19
RS: Radio Serial number.....	20
SP: Single press user defined switch action.....	20
SR: Selected Region.....	20
SW: Switch status.....	20

TD: Transponder TID value.....	21
TM: Time.....	21
UB: Unit Bootloader version number.....	21
UF: Unit Firmware version number.....	21
US: Unit Serial number.....	22
WW: Number of Words Written.....	22
Files on SD card.....	23
Commands.....	24
.al Alert Command.....	24
.ab Abort Command.....	25
.bc BarCode Command.....	26
.bl Battery Level Command.....	27
.bt <i>Bluetooth®</i> functions.....	28
.da Date Command.....	29
.dp User defined switch Double Press action.....	30
.ea Execute Autorun Command.....	31
.ec Echo.....	32
.fd Factory Defaults Command.....	33
.hc HID config Command	34
.hd HID configuration for double press switch action	35
.hs HID configuration for Single press switch action	37
.iv Inventory Command.....	38
.ki Kill command.....	40
.lk Licence Key.....	42
.lo Lock command.....	43
.mt Mount/Dismount internal memory.....	45
.pd Push Switch Double press.....	46
.ps Push Switch Single press.....	47
.ra Read the Autorun File.....	48
.rd Read transponder Command.....	49
.rl Read the Log file.....	51
.sa Switch Action Command.....	52
.sl Sleep.....	53
.sp User defined switch Single Press action.....	54
.sr Set Region.....	55
.ss Switch State Command.....	56
.st Sleep Timeout.....	57
.tm Time Command.....	58
.ts Transponder Select.....	59
.vr Version information Command.....	61
.wa Write command to Autorun file.....	62
.wr Write transponder Command.....	63
.ws Write Single transponder Command.....	65
Hardware Specific Connection Notes.....	67
About TSL.....	68
About	68
Contact	68

History

<u>Version</u>	<u>Date</u>	<u>Modifications</u>
2.0 Rev A	29/04/2013	First Release
2.1 Rev A	25/07/2013	Added Monza extensions, Fast ID, Blockwrite and Tag focus. Minor document formatting changes. Correction to the .da example, date should input as yy not yyyy. Correction to the .ws and .wr commands, 32 words can be input not 16. Added AC: response field. Added Bluetooth® error code. Changed the barcode escape character and enabled it by default. Added BR response for barcodes when escape is disabled.
2.1 Rev B	04/10/2013	Correction to the Version Information Command – added missing 'RS:' to the valid response field headers section .wr command default -qv value corrected was 6 should be 4. Hardware Specific Connection Notes section added
2.2 Rev A	16/05/2014	Amended the .rd –dl description to include the 253 word limit. Added the .lk command and LK: response. Fixed bug in .rd command which limited reads to a maximum 2032 bits. Fixed dropped <CRLF> bug in log when commanded from autorun file. Added –rd and –rs parameters to the .sa command to control the switch repeat delay. Added BA: response to the .vr command
2.3 Rev A	20/08/2014	Amended the .lk description to correct error in the maximum allowed length. Added “.sa –s ad –d ad -h” option for antenna determined switch action and haptic feedback. Added .hs and .hp commands for HID configuration. Added –ie an -fs parameters to .iv and .rd commands. Added –m parameter to .bt command.
2.3 Rev B	27/4/2015	.hd and .hs –td default parameter corrected .bt and .sa corrections ER:008 Modified to include Radio not fitted
2.4 Rev A	23/11/2015	Added .hc command Added EA:010 error code Changed .rl to allow –c off option from autorun Added no.log file to stop all logging .st –h minimum timeout changed to 1 second Added –qm option to .rd and .wr commands to support Tag QT command Added QT: and IA: response fields Added .mt command and no.mnt file to prevent FS mounting.
2.4 Rev B	06/05/2016	Added –e option to the .bt command

INTRODUCTION

This document describes the Technology Solutions ASCII 2 protocol. The commands and their parameters are detailed along with the responses. Each command has a few examples to aid understanding. The commands all have default parameters and most can be used without change.

It is important to note that this document is not a transponder tutorial and users should have a basic understanding of UHF Class 1 Gen 2 transponders.

The latest UHF Class 1 Gen 2 Standard is available for download from

<http://www.gs1.org/gsmp/kc/epcglobal/uhfc1g2>

"The *Bluetooth®* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by TSL is under license. Other trademarks and trade names are those of their respective owners."

COMMANDS OVERVIEW

All commands start with a period (.)(0x2E) followed by 2 lower case characters.

Commands should be terminated with a Carriage Return<CR>, a Linefeed<LF> or a combination of the two. All combinations are acceptable <CR>,<LF>,<CRLF> or <LFCR>.

Command echoing can be enabled with the .ec command. This is useful for testing commands with a terminal program but generally should be avoided particularly over the *Bluetooth®* interface where it will impact throughput.

Commands are parameterised with the parameters preceded by a minus sign (-)(0x2D)

e.g.

```
.rd -a00000000 -bu <CRLF>
```

Some parameter values need to be enclosed in double quotes ("')(0x22).

e.g.

```
.bt -f "1128-EU-000001" <CRLF>
```

All parameter values are stored in the reader, if a parameter is not included the stored value will be used.

When a command uses a parameter its stored value is updated.

When the reader is powered up the stored values are loaded with defaults with the exception of the .bt command whose settings are persistent.

The parameter -x restores the stored parameters to their default values.

The parameter -n prevents the command from taking any actions, other included parameters will be stored. This allows parameters to be saved without the command being performed.

The parameter -p displays the current values of the supported parameters. Any other parameters included will be stored first.

Once the command has started (. detected) a gap of greater than 30 seconds will cause an error response to be sent.

Spaces (0x20) in commands are ignored unless in quotes.

The command .<CRLF> will repeat the last command.

COMMAND PARSER

The Command Parser is fairly simple, only the expected parameters are validated, anything else will be ignored.

For example the following two commands will perform the same.

```
. al -v off <CRLF>  
.al this text is ignored -v off so is this <CRLF>
```

This is quite a useful feature as it can be used to identify the source of a command.

As an example, there may be a need to distinguish between a command issued over the USB interface and one issued from a trigger press. To achieve this, the commands sent via the USB interface could have "USB" inserted into the commands and then the .CS response can be used to separate the responses.

e.g.

Command from USB:

```
.iv USB <CRLF>
```

Response to command from USB:

```
CS: .iv USB <CRLF>  
EP: 310833B2DDD906C000001234<CRLF>  
EP: 341486E37C0000000004255<CRLF>  
EP: 341486E37C0000000004254<CRLF>  
OK:<CRLF><CRLF>
```

Response to .iv command issued from a switch press:

```
CS: .iv<CRLF>  
EP: 310833B2DDD906C000001234<CRLF>  
EP: 341486E37C0000000004255<CRLF>  
EP: 341486E37C0000000004254<CRLF>  
OK:<CRLF><CRLF>
```

If individual commands need to be identified a sequential numeric identifier could be used.

RESPONSES

Responses can return multiple values so field headers are used to separate the data.

Field headers are two upper case characters followed by a colon (:) (0x3A).

Each field is terminated by a Carriage Return Linefeed pair <CRLF>.

All responses end with either "OK: <CRLF><CRLF>" or "ER:nnn<CRLF><CRLF>"

For example, a typical response to the .vr command is:

```
CS: .vr<CRLF>
MF: Technology Solutions UK Ltd. <CRLF>
US: 1128-EU-000001<CRLF>
PV: V2.0.0<CRLF>
UF: V3.0.0<CRLF>
UB: V1.3.0<CRLF>
RS: 1116-ET-000001<CRLF>
RF: V2.6.0<CRLF>
RB: V1.2.0<CRLF>
AS: 1128-S1-EU-000001<CRLF>
OK:<CRLF><CRLF>
```

RESPONSE FIELD HEADERS

AB: AUTORUN FILE BEGIN

This field header indicates the beginning of the Autorun file and is terminated by <CRLF>.

Format:

AB: optional text <CRLF>

Examples:

AB: **** Beginning of Autorun file **** <CRLF>

AC: AUTHENTICATION CHIP TEST

This field header indicates the result of the test on the authentication chip and is terminated by <CRLF>.

Format:

AC: Passed/Failed <CRLF>

Examples:

AC: Passed <CRLF>

AE: AUTORUN FILE END

This field header indicates the end of the Autorun file and is terminated by <CRLF>.

Format:

AE: optional text <CRLF>

Examples:

AE: **** End of Autorun file **** <CRLF>

AS: ANTENNA SERIAL NUMBER

This field header precedes the antenna serial number which is terminated by <CRLF>.

Format:

AS: "Antenna serial number" <CRLF>

Examples:

AS: 1128-S1-EU-000001 <CRLF>

BA: BLUETOOTH® ADDRESS

This field header precedes the *Bluetooth®* address which is terminated by <CRLF>.

Format:

BA: "Bluetooth® Address" <CRLF>

Examples:

BA: 00:07:80:41:a4:c6 <CRLF>

BC: BARCODE DATA

This field header precedes the barcode value when escape characters are enabled (default) and is terminated by <CRLF>.

Since some barcodes can contain the termination characters<CRLF> the use of an escape character, <ESC> (0x1B), is used to distinguish between <CRLF> contained in the Barcode and the real termination characters. Should the escape character be read as part of the barcode it will be escaped as well.

Format:

BC: "Barcode Value" <CRLF>

Examples:

Example using escape character to read the following barcode data

"abc<ESC>123456789<CR><LF>abcdef"

BC: abc<ESC><ESC>123456789<ESC><CR><ESC><LF>abcdef <CRLF>

BP: BATTERY PERCENTAGE LEVEL

This field header precedes the battery level value which is terminated by <CRLF>.

Format:

BP: "Battery level Value" <CRLF>

Examples:

BP:100% <CRLF>

BP:78% <CRLF>

BP:4% <CRLF>

BR: BARCODE RAW

This field header precedes the barcode value when escape characters are disabled and is terminated by <CRLF>. Care must be taken since some barcodes can contain the termination characters <CRLF>.

Format:

BR: "Barcode Value" <CRLF>

Examples:

BR: ISBN:5884688-6686 <CRLF>

CH: CHARGE STATUS

This field header precedes charge status and is terminated by <CRLF>.

Format:

CH: Off/Charging/ Complete /Error<CRLF>

Examples:

CH: Complete<CRLF>

CR: TRANSPONDER EPC CRC VALUE

This field header precedes Transponder EPC CRC value (in hex) which is terminated by <CRLF>.

Format:

CR: "CRC Value" <CRLF>

Examples:

CR: 3E4F<CRLF>

CS: COMMAND STARTED

This field header is sent to indicate that a command has started. It precedes the command that initiated it and is terminated by <CRLF>.

Format:

CS: "Command" <CRLF>

Examples:

CS: bc -t 6<CRLF>

DA: DATE

This field header precedes the Date, in ISO 8601 extended format, terminated by <CRLF>.

Format:

DA: "Date" <CRLF>

Examples:

DA: 2013-01-24 <CRLF>

DP: DOUBLE PRESS USER DEFINED SWITCH ACTION

This field header precedes the action that will be executed when ".sa -d usr" is configured, it is terminated by <CRLF>.

Format:

DP: Switch command <CRLF>

Examples:

DP: .bc -t4 <CRLF>

DP: .iv <CRLF>

DT: DATE/TIME STAMP

This field header precedes the Time Stamp, in ISO 8601 extended format, terminated by <CRLF>.

Format:

DT: "Date/Time Stamp" <CRLF>

Examples:

DT: 2013-01-24T13:12:16 <CRLF>

EA: TRANSPONDER ACCESS ERROR CODE

This field header precedes the Transponder access error code and is terminated by <CRLF>. Access errors are generated by the reader while trying to access a transponder and apply to the transponder with the preceding EPC value.

Format:

EA:nnn<CRLF> nnn = 000 to 255

Error codes:

- 001 Handle mismatch.
- 002 CRC error on transponder response.
- 003 No transponder reply.
- 004 Invalid password.
- 005 Zero kill password.
- 006 Transponder lost.
- 007 Command format error.
- 008 Read count invalid.
- 009 Out of retries.
- 010 Access error.
- 255 Operation failed.

Examples:

EA:004<CRLF>

EA:006<CRLF>

EB: TRANSPONDER BACKSCATTER ERROR CODE

This field header precedes the Transponder backscatter error code and is terminated by <CRLF>. Backscatter errors are generated by the transponder and apply to the transponder with the preceding EPC value.

Format:

EB:nnn<CRLF> nnn = 000 to 255

Error codes:

- 000 General error.
- 003 Memory does not exist or the PC value is not supported.
- 004 Memory is lock or permlocked.
- 011 Transponder has insufficient power.
- 015 Transponder does not support error specific codes.

Examples:

EB:003<CRLF>

EB:011<CRLF>

EP: TRANSPONDER EPC VALUE

This field header precedes Transponder EPC value (in hex) which is terminated by <CRLF>.

Format:

EP: "EPC Value" <CRLF>

Examples:

EP: 00000000000000000000000010E6<CRLF>

ER: ERROR

This field header is used to terminate the response to an unsuccessful command.

It is always followed by a three digit error code then two Carriage return Linefeed pairs <CRLF><CRLF>.

Format:

ER:nnn<CRLF><CRLF> nnn = 000 to 255

Error codes:

- 001 Syntax Error.
- 002 Parameter not supported.
- 003 Action not enabled.
- 004 Command not supported by hardware
- 005 No transponder found
- 006 No Barcode found
- 007 Parameter configuration invalid
- 008 Antenna/Radio Error (Wrong region or Antenna/Radio Not Fitted)
- 009 Battery level too low
- 010 Scanner not ready
- 011 Command not supported on interface
- 012 Command not supported from Autorun file
- 013 Write Failure
- 014 Switch already in use
- 015 Command Aborted
- 016 Lock Failure
- 017 *Bluetooth®* Error
- 018 Licence Key is not blank
- 255 System Error.

Examples:

ER:001<CRLF><CRLF>

ER:004<CRLF><CRLF>

FN: BLUETOOTH® FRIENDLY NAME

This field header precedes the *Bluetooth®* friendly name and is terminated by <CRLF>.

Format:

FN: "Bluetooth® Friendly Name" <CRLF>

Examples:

FN: 1128-EU-000001 <CRLF>

IA: UHF API VERSION

This field header precedes the UHF API version number used for identifying the API in use, it is terminated by <CRLF>.

Format:

IA: "UHF API version number" <CRLF>

Examples:

IA: 1.5.0.10 <CRLF>

IX: INDEX NUMBER

This field header precedes an index number used for referencing multiple responses to a command, it is terminated by <CRLF>.

Format:

IX: 4 digit ASCII hex Index number <CRLF>

Examples:

IX: 004A <CRLF>

KS: KILL SUCCESS

This field header indicates the kill command has succeeded and is terminated by <CRLF>.

Format:

KS: Kill Success <CRLF>

Examples:

KS: Kill Success <CRLF>

LB: LOG BEGIN

This field header indicates the beginning of the log and is terminated by <CRLF>.

Format:

LB: optional text <CRLF>

Examples:

LB: **** Beginning of Log ****

LE: LOG END

This field header indicates the end of the log and is terminated by <CRLF>.

Format:

LE: optional text <CRLF>

Examples:

LE: **** End of Log **** <CRLF>

LE: **** End of Block **** <CRLF>

LL: LOG LENGTH

This field header precedes the length of the log file in bytes, it is terminated by <CRLF>.

Format:

LL: 8 digit ASCII hex Index number <CRLF>

Examples:

LL: 0000004A <CRLF>

LK: LICENCE KEY

This field header precedes the licence key string and is terminated by <CRLF>.

Any printable ASCII characters are allowed.

Format:

LK: licence Key <CRLF>

Examples:

LK: IamALicenceKey <CRLF>

LS: LOCK SUCCESS

This field header indicates the lock command has succeeded and is terminated by <CRLF>.

Format:

LS: Lock Success <CRLF>

Examples:

LS: Lock Success <CRLF>

ME: MESSAGE

This field header precedes message text and is terminated by <CRLF>.

It usually precedes the ER: field header to provide additional error information.

Format:

ME: "Message text" <CRLF>

Examples:

ME: "Vibration not supported" <CRLF>

MF: MANUFACTURER NAME

This field header precedes the manufacturers name and is terminated by <CRLF>.

Format:

MF: "Manufacturer name" <CRLF>

Examples:

MF: Technology Solutions UK Ltd. <CRLF>

OK: OK RESPONSE

This field header is used to terminate the response to a successful command.

It is always followed by two Carriage return Linefeed pairs <CRLF><CRLF>.

Format:

OK:<CRLF><CRLF>

Examples:

OK:<CRLF><CRLF>

QT: QT CONTROL WORD

This field header precedes the 16 bit QT control word (in hex) and is terminated by <CRLF>.

Format:

QT: "QT Value" <CRLF>

Examples:

QT: 4000<CRLF>

PC: TRANSPONDER EPC PC VALUE

This field header precedes Transponder EPC PC value (in hex) which is terminated by <CRLF>.

Format:

PC: "PC Value" <CRLF>

Examples:

PC: 3000<CRLF>

PR: PARAMETERS

This field header precedes parameter values which are terminated by <CRLF>.

Format:

PR: "Parameter Values" <CRLF>

Examples:

PR: -v on -b off <CRLF>

PV: PROTOCOL VERSION NUMBER

This field header precedes the protocol version number which is terminated by <CRLF>.

Format:

PV: "Protocol version number" <CRLF>

Examples:

PV: 2.4.0<CRLF>

RB: RADIO BOOTLOADER VERSION NUMBER

This field header precedes the radio bootloader version number which is terminated by <CRLF>.

Format:

RB: "Radio bootloader version number" <CRLF>

Examples:

RB:V1.2.0<CRLF>

RD: TRANSPONDER READ DATA

This field header precedes data read from a Transponder (in hex) which is terminated by <CRLF>.

Format:

RD: "Read Data" <CRLF>

Examples:

RD: 0F078010<CRLF>

RF: RADIO FIRMWARE VERSION NUMBER

This field header precedes the radio firmware version number which is terminated by <CRLF>.

Format:

RF: "Radio firmware version number" <CRLF>

Examples:

RF:V2.6.0<CRLF>

RI: TRANSPONDER RSSI VALUE

This field header precedes Transponder RSSI value in dBm which is terminated by <CRLF>.

Format:

RI: "RSSI Value" <CRLF>

Examples:

RI: -63<CRLF>

RS: RADIO SERIAL NUMBER

This field header precedes the radio serial number which is terminated by <CRLF>.

Format:

RS: "Radio serial number" <CRLF>

Examples:

RS: 1116-ET-000001 <CRLF>

SP: SINGLE PRESS USER DEFINED SWITCH ACTION

This field header precedes the action that will be executed when ".sa -s usr" is configured, it is terminated by <CRLF>.

Format:

SP: Switch command <CRLF>

Examples:

SP: .bc -t4 <CRLF>

SP: .iv <CRLF>

SR: SELECTED REGION

This field header precedes the currently selected region and is terminated by <CRLF>.

Format:

SR: region Code <CRLF>

Examples:

SR: us <CRLF>

SR: eu <CRLF>

SW: SWITCH STATUS

This field header precedes the switch state value and is terminated by <CRLF>.

Format:

SW: "off/single/double" <CRLF>

Examples:

SW: single <CRLF>

SW: off <CRLF>

TD: TRANSPONDER TID VALUE

This field header precedes the Transponder TID value (in hex) which is terminated by <CRLF>.

Format:

TD: "TID Value" <CRLF>

Examples:

TD: 1C2B3A495867768594A3B2C1<CRLF>

TM: TIME

This field header precedes the Time, in ISO 1601 extended format, terminated by <CRLF>.

Format:

TM: "Time" <CRLF>

Examples:

TM: 13:12:16 <CRLF>

UB: UNIT BOOTLOADER VERSION NUMBER

This field header precedes the unit bootloader version number which is terminated by <CRLF>.

Format:

UB: "Unit bootloader version number" <CRLF>

Examples:

UB:V1.2.0<CRLF>

UF: UNIT FIRMWARE VERSION NUMBER

This field header precedes the unit firmware version number which is terminated by <CRLF>.

Format:

UF: "Unit firmware version number" <CRLF>

Examples:

UF:V2.6.0<CRLF>

US: UNIT SERIAL NUMBER

This field header precedes the unit serial number which is terminated by <CRLF>.

Format:

US: "Unit serial number" <CRLF>

Examples:

US: 1128-EU-000001 <CRLF>

WW: NUMBER OF WORDS WRITTEN

This field header precedes the number of words successfully written by a transponder write command and is terminated by <CRLF>.

Format:

WW: nn <CRLF>

Examples:

WW: 3 <CRLF>

FILES ON SD CARD

On wake up the default configuration is loaded. If the “auto.txt” file is present on the SD card it is executed as if sent from a host. This may overwrite some or the entire loaded configuration.

Files on SD

AUTO.TXT Script which runs on start up

LOG.TXT Event log file

no.log If present all logging is disabled

no.mnt If present it prevents the internal memory from automatically mounting when a USB connection is established.

COMMANDS

.al ALERT COMMAND

Configures and alerts the user.

Returns an error if vibrate and buzzer are both off.

Parameters:

-b on/off	Buzzer on or off
-d sho/med/lon	Buzzer/Vibrate duration short, medium or long
-n	No action, just set the parameters
-p	List the current parameter values
-t low/med/hig	Buzzer tone low, medium or high
-v on/off	Vibrate on or off
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted in the following order.

-x, -b, -d, -t, -v, -p, -n

Parameter defaults

The parameter defaults are:

-b on, -d sho, -t hig, -v on,

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.al -bon -voff <CRLF>	CS: .al -bon -voff <CRLF> OK: <CRLF> <CRLF>	Buzzer sounds
.al -p -n <CRLF>	CS: .al -p -n <CRLF> PR: -b on -d sho -n -p -t hig -v off -x<CRLF> OK:<CRLF><CRLF>	None
.al -boff -voff <CRLF>	CS: .al -boff -voff <CRLF> ME: Buzz and Vibrate are both off<CRLF> ER:003<CRLF><CRLF>	None

.ab ABORT COMMAND

Abort command, terminates the current command and any pending commands. It also stops any software switch presses that are in progress.

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: ER: ME: OK:

Examples:

Command	Response	Action
.ab <CRLF>	CS: .ab<CRLF> OK: <CRLF> <CRLF>	Abort complete

.bc BARCODE COMMAND

Initiates a barcode read.

Returns an error if no barcode is read.

Parameters:

-al on/off	perform an alert after a successful barcode read using the current alert parameters from the .al command
-dt on/off	Include date time response
-e on/off	Use escape character 0x1B to precede <CR>, <LF> and itself
-n	No action, just set the parameters
-p	List the current parameter values
-tn n=1..9	Read duration in seconds
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -al, -e, -dt, -t, -p, -n

Parameter defaults

The parameter defaults are:

-al on, -dt off, -e on, -t 9

Valid response field headers:

BC: BR: CS: DT: ER: ME: OK: PR:

Examples:

Command	Response	Action
.bc <CRLF>	CS: .bc<CRLF> BC: ISBN:5884688-6686 <CRLF> OK: <CRLF> <CRLF>	Barcode reads
.bc -e off<CRLF>	CS: .bc -e off<CRLF> BR: ISBN:5884688-6686 <CRLF> OK: <CRLF> <CRLF>	Barcode reads with escape
.bc <CRLF>	CS: .bc<CRLF> ME: No barcode found<CRLF> ER:006<CRLF><CRLF>	Barcode fails to read
.bc -p -n <CRLF>	CS: .bc -p -n <CRLF> PR: -al on -dt off -e on -n -p -t 9 -x <CRLF> OK:<CRLF><CRLF>	None

.bl BATTERY LEVEL COMMAND

Returns Battery level as percentage and Charge status.

Parameters:

No parameters are used for this command.

Valid response field headers:

CH: CS: BP: ER: ME: OK:

Examples

Command	Response	Action
.bl <CRLF>	CS: .bl<CRLF> BP: 100% <CRLF> CH: Complete <CRLF> OK:<CRLF><CRLF>	None
.bl <CRLF>	CS: .bl<CRLF> BP: 30% <CRLF> CH: Charging <CRLF> OK:<CRLF><CRLF>	None
.bl <CRLF>	CS: .bl<CRLF> BP: 7% <CRLF> CH: Off <CRLF> OK:<CRLF><CRLF>	None

.bt BLUETOOTH® FUNCTIONS

Reads the *Bluetooth®* address, additionally the *Bluetooth®* can be reset and configured. This command is only available over the USB interface and cannot be used in the Autorun file.

Settings made with this command are persistent and not reset to defaults at power up.

Parameters:

-bi "bundleID"	set iOS Bundle ID, up to 80 characters, enclosed in double quotes ("")
-e on/off	Turn <i>Bluetooth®</i> on or off
-bs "BundleSeedID"	set iOS Bundle Seed ID, 10 characters enclosed in double quotes ("")
-f "name"	set the <i>Bluetooth®</i> friendly name, up to 20 characters, enclosed in double quotes ("")
-m spp/hid	Set <i>Bluetooth®</i> for either HID or SPP mode, -x is implied as a full reset will be performed.
-p	List the available parameters (not their values)
-w nnnn	set the 4 character pairing code
-x	reset <i>Bluetooth®</i> settings to defaults for current mode (HID or SPP)

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -f, -w, -bi, -bs, -p

Parameter defaults

-bi "TSL demo app Bundle ID", -bs "TSL demo app Bundle Seed ID",
 -f "unit serial number", -m spp, -w 0000, -x

Valid response field headers:

AC: BA: CS: ER: FN: ME: OK: PR:

Examples:

Command	Response	Action
.bt <CRLF>	CS: .bt<CRLF> BA: 00:07:80:41:a4:c6 <CRLF> FN: 1128-EU-000001 <CRLF> AC: Passed <CRLF> OK: <CRLF> <CRLF>	The <i>Bluetooth®</i> address and friendly name is read and the authentication chip is working.
.bt -w 0123 <CRLF>	CS: .bt -w 0123 <CRLF> BA: 00:07:80:41:a4:c6 <CRLF> FN: 1128-EU-000001 <CRLF> AC: Passed <CRLF> OK: <CRLF> <CRLF>	The <i>Bluetooth®</i> pairing code is set to 0123

.da DATE COMMAND

Reads or sets the date.

Parameters:

-s yymmdd Set the date

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-s

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: DA: ER: ME: OK:

Examples:

Command	Response	Action
.da <CRLF>	CS: .da<CRLF> DA: 2012-11-05<CRLF> OK: <CRLF> <CRLF>	The date is read
.da -s 130120<CRLF>	CS: .da -s 130120<CRLF> DA: 2013-01-20<CRLF> OK: <CRLF> <CRLF>	The date is set

.dp USER DEFINED SWITCH DOUBLE PRESS ACTION

Reads or sets the double press user action used when “.sa -d usr” is configured.

Parameters:

-s user action command Set the user action

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-s

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: ER: ME: OK: DP:

Examples:

Command	Response	Action
.dp <CRLF>	CS: .dp<CRLF> DP: .bc<CRLF> OK: <CRLF> <CRLF>	User action is read
.dp -s .iv<CRLF>	CS: .dp -s .iv<CRLF> DP: .iv<CRLF> OK: <CRLF> <CRLF>	User action is set

.ea EXECUTE AUTORUN COMMAND

This command will force the autorun file to run.

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: ER: ME: OK:

Examples:

Command	Response	Action
.ea <CRLF>	CS: .ea<CRLF> OK: <CRLF> <CRLF>	Auto.txt will be run

.ec ECHO

Determines whether commands are echoed back to the host.

Parameters:

- e on/off Turn echo on or off
- p List the current parameter values
- x Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -e, -p

Parameter defaults

The parameter defaults are:

-e off

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.ec -x <CRLF>	CS: .ec -x<CRLF> OK: <CRLF> <CRLF>	.ec defaults loaded
.ec -p <CRLF>	CS: .ec -p<CRLF> PR: -e off -p -x <CRLF> OK:<CRLF><CRLF>	None

.fd FACTORY DEFAULTS COMMAND

Restores all command parameters to their default settings.

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: ER: ME: OK:

Examples:

Command	Response	Action
.fd <CRLF>	CS: .fd<CRLF> OK: <CRLF> <CRLF>	Reset complete

.hc HID CONFIG COMMAND

Defines settings for HID.

Parameters:

-cd xxx	Sets the delay between characters sent via HID Where xxx is a value between 0 and 999 ms
-p	List the current parameter values
-tm x	Sets the trigger mode, where x is: 0 Single shot, trigger cancels after one operation. 1 Read until, trigger cancels on success or trigger release. 2 While pressed, trigger cancels only on trigger release.
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -cd, -p

Parameter defaults

The parameter defaults are:

-cd 0 -tm 1

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.hc -x <CRLF>	CS: .hc -x<CRLF> OK: <CRLF> <CRLF>	.sa defaults loaded
.hc -p <CRLF>	CS: .hc -p<CRLF> PR: -cd 0 -p -x <CRLF> OK:<CRLF><CRLF>	None
.hc -cd 100 <CRLF>	CS: .hc -cd 100<CRLF> OK:<CRLF><CRLF>	Set the inter-character delay to 100ms

.hd HID CONFIGURATION FOR DOUBLE PRESS SWITCH ACTION

Controls how data is presented when *Bluetooth®* is configured for HID by the .bt command.

Parameters:

-bh	xxyy*	Header key codes that preceded a Barcode
-bt	xxyy*	Termination key codes that follow a Barcode
-dh	xxyy*	Header key codes that preceded a transponder data
-dt	xxyy*	Termination key codes that follow a transponder data
-eh	xxyy*	Header key codes that preceded a transponder EPC
-et	xxyy*	Termination key codes that follow a transponder EPC
-ih	xxyy*	Header key codes that preceded an inventory cycle
-it	xxyy*	Termination key codes that follow an inventory cycle
-p		List the current parameter values
-rh	xxyy*	Header key codes that preceded a read cycle
-rt	xxyy*	Termination key codes that follow a read cycle
-td	asc/hex	Determines how transponder data is sent asc - data is assumed to be ASCII text and is sent as is. hex - data is assumed to be raw and is sent as ASCII hex.
-x		Reset the parameters to defaults

*Where xx is the KeyCode for the first key sent and yy is the second. See below for valid KeyCodes.

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -bh, -bt, -dh, -dt, -eh, -et, -ih, -it, -rh, -rt, -td, -p

Parameter defaults

The parameter defaults are:

-bh ffff -bt 0dff -dh ffff -dt 0dff -eh ffff -et 0dff -ih ffff -it ffff -rh ffff -rt ffff -td hex

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.hd -x <CRLF>	CS: .hd -x<CRLF> OK: <CRLF> <CRLF>	.hd defaults loaded
.hd -p <CRLF>	CS: .hd -p<CRLF> PR: -bh ffff -bt 0dff -dh ffff -dt 0dff -eh ffff -et 0dff -ih ffff -it ffff -rh ffff -rt ffff -td asc <CRLF> OK:<CRLF><CRLF>	None

Keycode	Key
00	Left control + space
01	Left control + a
02	Left control + b
03	Left control + c
04	Left control + d
05	Left control + e
06	Left control + f
07	Left control + g
08	Backspace
09	Tab
0a	Enter
0b	Left control + k
0c	Left control + l
0d	Enter
0e	Left control + n
0f	Left control + o
10	Left control + p
11	Left control + q
12	Left control + r
13	Left control + s
14	Left control + t
15	Left control + u
16	Left control + v
17	Left control + w
18	Left control + x
19	Left control + y
1a	Left control + z
1b	Left control + space
1c	Esc
20-7e	Corresponding ASCII character
7f	backspace
80	Cursor up
81	Cursor right
82	Cursor down
83	Cursor left
84	Insert
85	Delete
86	Home
87	End
88	Page up
89	Page down
ff	No key pressed

.hs HID CONFIGURATION FOR SINGLE PRESS SWITCH ACTION

Controls how data is presented when Bluetooth® is configured for HID by the .bt command.

Parameters:

-bh	xxyy*	Header key codes that preceded a Barcode
-bt	xxyy*	Termination key codes that follow a Barcode
-dh	xxyy*	Header key codes that preceded a transponder data
-dt	xxyy*	Termination key codes that follow a transponder data
-eh	xxyy*	Header key codes that preceded a transponder EPC
-et	xxyy*	Termination key codes that follow a transponder EPC
-ih	xxyy*	Header key codes that preceded an inventory cycle
-it	xxyy*	Termination key codes that follow an inventory cycle
-p		List the current parameter values
-rh	xxyy*	Header key codes that preceded a read cycle
-rt	xxyy*	Termination key codes that follow a read cycle
-td	asc/hex	Determines how transponder data is sent asc - data is assumed to be ASCII text and is sent as is. hex - data is assumed to be raw and is sent as ASCII hex.
-x		Reset the parameters to defaults

*Where xx is the KeyCode for the first key sent and yy is the second. See above for valid KeyCodes.

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -bh, -bt, -dh, -dt, -eh, -et, -ih, -it, -rh, -rt, -td, -p

Parameter defaults

The parameter defaults are:

-bh ffff -bt 0dff -dh ffff -dt 0dff -eh ffff -et 0dff -ih ffff -it ffff -rh ffff -rt ffff -td hex

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.hs -x <CRLF>	CS: .hs -x<CRLF> OK: <CRLF> <CRLF>	.hs defaults loaded
.hs -p <CRLF>	CS: .hs -p<CRLF> PR: -bh ffff -bt 0dff -dh ffff -dt 0dff -eh ffff -et 0dff -ih ffff -it ffff -rh ffff -rt ffff -td asc <CRLF> OK:<CRLF><CRLF>	None

.iv INVENTORY COMMAND

Performs an inventory of transponders within the read range of the reader.
Returns an error if no transponders are found.

Parameters:

-al on/off	perform an alert after a successful inventory using the current alert parameters from the .al command
-c on/off	Include EPC checksum response
-dt on/off	Include date time response
-e on/off	Include EPC PC information response
-fi on/off	Impinj fast ID extension. If set, Transponders which support this feature will include their TID in the response
-fs on/off	filter out all but the strongest RSSI response
-ie on/off	Include the EPC response
-io on/off	Inventory only, if set to on then no select will be performed before the inventory round is started
-ix on/off	Index number each transponder response
-n	No action, just set the parameters
-o nn	Output power in dBm, where nn is in the range 10 to 29
-p	List the parameter and their current values
-qa fix/dyn	Q algorithm
-ql all/ns1/sl	query Select
-qs s0,s1,s2,s3	query Session
-qt a/b	query Target
-qv nn	Q value for fixed Q operations (0-15)
-r on/off	Include transponder RSSI response
-sa n	Select action

Parameter n=	Matching Action		Non Matching Action	
	SL Flag	Session Flag	SL Flag	Session Flag
0	assert	Set A	deassert	Set B
1	assert	Set A	nothing	nothing
2	nothing	nothing	deassert	Set B
3	toggle	toggle	nothing	nothing
4	deassert	Set B	assert	Set A
5	deassert	Set B	nothing	nothing
6	nothing	nothing	assert	Set A
7	nothing	nothing	toggle	toggle

-sb epc/tid/usr	Bank to use for the select mask
-sd xx..zz	Select mask data in 2 character ASCII Hex pairs padded to ensure full bytes
-sl xx	Length in bits of the select mask, where xx is a 2 character ASCII Hex value
-so xxxx	Number of bits from the start of the block to the start of the select mask, where xxxx is a 4 character ASCII Hex value
-st s0,s1,s2,s3,sl	Select target
-tf on/off	Impinj tag focus extension. Only effective if qs=s1, qt=a and if supported by the transponder.
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -al, -c, -e, -r, -ie, -dt, -fs, -ix, -sb, -so, -sl, -sd, -o, -io, -sa, -st, -qa, -ql, -qs, -qt, -qv, -fi, -tf, -p, -n

Parameter defaults

The parameter defaults are:

-al on, -c off, -dt off, -e off, -fi off, -fs off, -ie on, -io on, -ix off, -o 29, -qa dyn, -ql all, -qs s1, -qt a, -qv 6, -r off, -sa 0, -sb epc, -sd, -sl 00, -so 0000, -st s1, -tf off

Valid response field headers:

CR: CS: DT: EP: ER: IX: ME: OK: PC: PR: RI: TD:

Examples:

Command	Response	Action
.iv -p -n <CRLF>	CS: .iv -p -n<CRLF> PR: -al on -c off -dt off -e off -fi off -fs off ie on -io on -ix off -n -o 29 -p -qa dyn -ql all -qs s1 -qt a -qv 6 -r off -sa 0 -sb epc -sd -sl 00 -so 0000 -st s1 -tf off -x<CRLF> OK:<CRLF><CRLF>	none
.iv <CRLF>	CS: .iv<CRLF> EP: 310833B2DDD906C000001234<CRLF> EP: 341486E37C00000000004255<CRLF> EP: 341486E37C00000000004254<CRLF> OK:<CRLF><CRLF>	3 transponders read
.iv -dt on -e on <CRLF>	CS: .iv -dt on -e on <CRLF> DT: 2000-01-26T19:00:52<CRLF> EP: 341486E37C00000000004254<CRLF> PC: 3000<CRLF> EP: 341486E37C00000000004255<CRLF> PC: 3000<CRLF> EP: 310833B2DDD906C000001234<CRLF> PC: 3000<CRLF> OK:<CRLF><CRLF>	3 transponders read

.ki KILL COMMAND

This command is used to kill transponders. The selected transponders with matching access and kill passwords will be permanently killed.

Parameters:

-ap xxxxxxxx	Access password, where xxxxxxxx is an 8 character ASCII Hex value
-c on/off	Include EPC checksum response
-dt on/off	Include date time response
-e on/off	Include EPC PC information response
-io on/off	Inventory only, if set to on then no select will be performed before the inventory round phase is started
-ix on/off	Index number each transponder response
-kp xxxxxxxx	Kill password, where xxxxxxxx is an 8 character ASCII Hex value
-n	No action, just set the parameters
-o nn	Output power in dBm, where nn is in the range 10 to 29
-p	List the parameter and their current values
-ql all/ns1/sl	query Select
-qs s0,s1,s2,s3	query Session
-qt a/b	query Target
-qv nn	Q value (0-15)
-r on/off	Include transponder RSSI response
-sa n	Select action

Parameter n=	Matching Action		Non Matching Action	
	SL Flag	Session Flag	SL Flag	Session Flag
0	assert	Set A	deassert	Set B
1	assert	Set A	nothing	nothing
2	nothing	nothing	deassert	Set B
3	toggle	toggle	nothing	nothing
4	deassert	Set B	assert	Set A
5	deassert	Set B	nothing	nothing
6	nothing	nothing	assert	Set A
7	nothing	nothing	toggle	toggle

-sb epc/tid/usr	Bank to use for the select mask
-sd xx..zz	Select mask data in 2 character ASCII Hex bytes padded to ensure full bytes, up to a maximum of 32 bytes.
-sl xx	Length in bits of the select mask, where xx is a 2 character ASCII Hex value
-so xxxx	Number of bits from the start of the block to the start of the select mask, where xxxx is a 4 character ASCII Hex value
-st s0,s1,s2,s3,sl	Select target
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -c, -e, -r, -dt, -ix, -sb, -so, -sl, -sd, -o, -io, -sa, -st, -ql, -qs, -qt, -qv, -ap, -kp, -p, -n

Parameter defaults

The parameter defaults are:

-ap 00000000, -c off, -dt off, -e off, -io off, -ix off, -kp 00000000, -o 29, -ql all, -qs s1,
 -qt b, -qv 2, -r off, -sa 4, -sb epc, -sd, -sl 00, -so 0000, -st s1

Valid response field headers:

CR: CS: DT: EA: EB: EP: ER: IX: KS: ME: OK: PC: PR: RI:

Examples:

Command	Response	Action
.ki -p -n <CRLF>	CS: .ki -p -n <CRLF> PR: -ap 00000000 -c off -dt off -e off -io off -ix off -kp 00000000 -n -o 29 -p -ql all -qs s1 -qt b -qv 2 -r off -sa 4 -sb epc -sd 3005FB63AC1F3681EC880468 -sl 60 -so 0020 -st s1 -x <CRLF> OK: <CRLF><CRLF>	No Action
.ki -ap 00000001 -kp 00000001<CRLF>	CS: .ki -ap 00000001 -kp 00000001 <CRLF> EP: 3005FB63AC1F3841EC880467 <CRLF> KS: Kill Success <CRLF> OK: <CRLF> <CRLF>	Transponder is killed

.lk LICENCE KEY

This command reads, writes and deletes the Licence Key stored in the reader's non-volatile memory. The Licence Key can be up to 255 characters long and can contain any printable characters with the exception of double quotes (").

How the licence key function is used is up to the programmer, it could be used to store a simple password or some form of hashing could be used with the two unique strings, the serial number and *Bluetooth®* address, returned from the .vr command.

Parameters:

- | | |
|------------------|---|
| -d yes | Delete the Licence Key |
| -p | List the parameters |
| -s "Licence Key" | Set the licence key, up to 255 characters, enclosed in double quotes(").The licence key can contain any printable character except for double quotes ("). The Licence key can only be written if it is currently blank. |

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-d, -s, -p

Valid response field headers:

CS: ER: LK: ME: OK: PR:

Examples:

Command	Response	Action
.lk -p <CRLF>	CS: .lk -p<CRLF> PR: -d -p -s<CRLF> LK: ThisIsMyLicenceKey<CRLF> OK: <CRLF> <CRLF>	Licence key and parameters read
.lk -d yes -s "NewLicence" <CRLF>	CS:.lk -d yes -s "NewLicence" <CRLF> LK: NewLicence<CRLF> OK: <CRLF> <CRLF>	New licence key written

.Io LOCK COMMAND

This command is used to control access to the memory banks and passwords of the selected transponders. The lock is controlled by a 20 bit lock payload, please refer to the latest UHF Class 1 Gen 2 Standard for details. Care should be taken since some lock actions are permanent.

Parameters:

-ap xxxxxxxx	Access password, where xxxxxxxx is an 8 character ASCII Hex value
-c on/off	Include EPC checksum response
-dt on/off	Include date time response
-e on/off	Include EPC PC information response
-io on/off	Inventory only, if set to on then no select will be performed before the inventory round phase is started
-ix on/off	Index number each transponder response
-lp xxxx	20 bit Lock command payload where xxxx is a 5 character ASCII Hex value
-n	No action, just set the parameters
-o nn	Output power in dBm, where nn is in the range 10 to 29
-p	List the parameter and their current values
-ql all/ns1/sl	query Select
-qs s0,s1,s2,s3	query Session
-qt a/b	query Target
-qv nn	Q value (0-15)
-r on/off	Include transponder RSSI response
-sa n	Select action

Parameter n=	Matching Action		Non Matching Action	
	SL Flag	Session Flag	SL Flag	Session Flag
0	assert	Set A	deassert	Set B
1	assert	Set A	nothing	nothing
2	nothing	nothing	deassert	Set B
3	toggle	toggle	nothing	nothing
4	deassert	Set B	assert	Set A
5	deassert	Set B	nothing	nothing
6	nothing	nothing	assert	Set A
7	nothing	nothing	toggle	toggle

-sb epc/tid/usr	Bank to use for the select mask
-sd xx..zz	Select mask data in 2 character ASCII Hex bytes padded to ensure full bytes, up to a maximum of 32 bytes.
-sl xx	Length in bits of the select mask, where xx is a 2 character ASCII Hex value
-so xxxx	Number of bits from the start of the block to the start of the select mask, where xxxx is a 4 character ASCII Hex value
-st s0,s1,s2,s3,sl	Select target
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -c, -e, -r, -dt, -ix, -sb, -so, -sl, -sd, -o, -io, -sa, -st, -ql, -qs, -qt, -qv, -lp, -ap, -p, -n

Parameter defaults

The parameter defaults are:

-ap 00000000, -c off, -dt off, -e off, -io off, -ix off, -lp 00000, -o 29, -ql all, -qs s1,
 -qt b, -qv 2, -r off, -sa 4, -sb epc, -sd, -sl 00, -so 0000, -st s1

Valid response field headers:

CR: CS: DT: EA: EB: EP: ER: IX: LS: ME: OK: PC: PR: RI:

Examples:

Command	Response	Action
.lo -n -p<CRLF>	CS: .lo -n -p <CRLF> PR: -ap 00000000 -c off -dt off -e off -io off -ix off -lp 00000 -n -o 29 -p -ql all -qs s1 -qt b -qv 2 -r off -sa 4 -sb epc -sd -sl 00 -so 0000 -st s1 -x <CRLF> OK: <CRLF><CRLF>	No Action
.lo -lp 08020 -ap 00000001<CRLF>	CS: .lo -lp 08020 -ap 00000001<CRLF> EP: 3005FB63AC1F3681EC880468 <CRLF> LS: Lock Success <CRLF> OK: <CRLF><CRLF>	EPC memory bank lock is set so it is writable only in the secured state

.mt MOUNT/DISMOUNT INTERNAL MEMORY

Mounts or Dismounts the internal memory, when connected via USB, on readers that support internal memory.

Parameters:

- d Dismount the internal storage
- m Mount the internal storage
- p List the parameters

Parameter interpretation order

The parameters are interpreted and applied in the following order.

- d, -m, -p

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.mt -p <CRLF>	CS: .mt -p<CRLF> PR: -d -m -p<CRLF> OK: <CRLF> <CRLF>	No Action
.mt -m<CRLF>	CS: .mt -m<CRLF> ME: Mounting internal memory<CRLF> OK: <CRLF> <CRLF>	The internal memory was mounted

.pd PUSH SWITCH DOUBLE PRESS

Starts a timed software switch double press, this is equivalent to a double press and hold of the hardware switch. If the switch is already in use an error will be returned. If the duration is set to zero the switch press will continue until stopped with an abort command. If the switch action is set to barcode then the switch press will end on completion of the barcode read.

Parameters:

-n	No action, just set the parameters
-p	List the current parameter values
-tn n=0..99	Press duration in seconds
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -t, -p, -n

Parameter defaults

The parameter defaults are:

-t 5

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.pd -p -n <CRLF>	CS: .pd -p -n<CRLF> PR: -n -p -t 5 -x<CRLF> OK: <CRLF> <CRLF>	No Action
.pd <CRLF>	CS: .pd<CRLF> ME: Switch already in use<CRLF> ER:014<CRLF><CRLF>	The switch press was refused because the switch was already in use

.ps PUSH SWITCH SINGLE PRESS

Starts a timed software switch single press, this is equivalent to a single press and hold of the hardware switch. If the switch is already in use an error will be returned. If the duration is set to zero the switch press will continue until stopped with an abort command. If the switch action is set to barcode then the switch press will end on completion of the barcode read.

Parameters:

-n	No action, just set the parameters
-p	List the current parameter values
-tn n=0..99	Press duration in seconds
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -t, -p, -n

Parameter defaults

The parameter defaults are:

-t 5

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.ps -p -n <CRLF>	CS: .ps -p -n<CRLF> PR: -n -p -t 5 -x<CRLF> OK: <CRLF> <CRLF>	No Action
.ps <CRLF>	CS: .ps<CRLF> ME: Switch already in use<CRLF> ER:014<CRLF><CRLF>	The switch press was refused because the switch was already in use

.ra READ THE AUTORUN FILE

Reads the Autorun file, additionally the Autorun file can be deleted. This command cannot be used in the Autorun file.

Parameters:

-d yes delete the Autorun file

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-d

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: ER: AB: AE: ME: OK:

Potentially any other response field could be contained in the log file.

Examples:

Command	Response	Action
.ra <CRLF>	CS: .ra<CRLF> AB: <i>Autorun</i> file data AE: OK: <CRLF> <CRLF>	The autorun file is read
.ra -d yes <CRLF>	CS: .ra -d yes <CRLF> OK: <CRLF> <CRLF>	The autorun file is deleted

.rd READ TRANSPONDER COMMAND

Performs an inventory of transponders within the read range of the reader and then reads the data from the requested bank. Returns an error if no transponders are found.

Parameters:

-al on/off	perform an alert after a successful read using the current alert parameters from the .al command
-ap xxxxxxxx	Access password, where xxxxxxxx is an 8 character ASCII Hex value
-c on/off	Include EPC checksum response
-db epc/tid/usr/res	Data bank to read from
-dl xx	Data length, size of the data to read (number of 16 bit words in the range 1 to 253 decimal i.e. 01 to FD hex), where xx is a 2 character ASCII Hex value
-do xxxx	Data offset, the number of 16 bit words, from the start of the block, to start read from, where xxxx is a 4 character ASCII Hex value
-dt on/off	Include date time response
-e on/off	Include EPC PC information response
-fs on/off	filter out all but the strongest RSSI response
-ie on/off	Include the EPC response
-io on/off	Inventory only, if set to on then no select will be performed before the inventory round phase is started
-ix on/off	Index number each transponder response
-n	No action, just set the parameters
-o nn	Output power in dBm, where nn is in the range 10 to 29
-p	List the parameter and their current values
-ql all/ns1/sl	query Select
-qm n	QT mode n = 0 Standard read n = 1 Read from private memory n = 2 Read from private memory short range n = 3 Read the QT control word
-qs s0,s1,s2,s3	query Session
-qt a/b	query Target
-qv nn	Q value (0-15)
-r on/off	Include transponder RSSI response
-sa n	Select action
-sb epc/tid/usr	Bank to use for the select mask
-sd xx..zz	Select mask data in 2 character ASCII Hex bytes padded to ensure full bytes, up

Parameter n=	Matching Action		Non Matching Action	
	SL Flag	Session Flag	SL Flag	Session Flag
0	assert	Set A	deassert	Set B
1	assert	Set A	nothing	nothing
2	nothing	nothing	deassert	Set B
3	toggle	toggle	nothing	nothing
4	deassert	Set B	assert	Set A
5	deassert	Set B	nothing	nothing
6	nothing	nothing	assert	Set A
7	nothing	nothing	toggle	toggle

-sl xx	to a maximum of 32 bytes.
-so xxxx	Length in bits of the select mask, where xx is a 2 character ASCII Hex value
-st s0,s1,s2,s3,s1	Number of bits from the start of the block to the start of the select mask, where xxxx is a 4 character ASCII Hex value
-x	Select target

Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -al, -c, -e, -r, -ie, -dt, -fs, -ix, -sb, -so, -sl, -sd, -o, -io, -qm -sa, -st, -ql, -qs, -qt, -qv, -db, -do, -ap, -dl, -p, -n

Parameter defaults

The parameter defaults are:

-al on, -ap 00000000, -c off, -db epc, -dl 02, -do 0000, -dt off, -e off, -fs off, -ie on, -io off, -ix off -o 29, -ql all, -qm 0 -qs s2, -qt b, -qv 6, -r off, -sa 4, -sb epc, -sd, -sl 00, -so 0000, -st s2

Valid response field headers:

CR: CS: DT: EA: EB: EP: ER: IX: ME: OK: PC: PR: QT: RD: RI:

Examples:

Command	Response	Action
.rd -p -n <CRLF>	CS: .rd -p -n<CRLF> PR: -al on -ap 00000000 -c off -db epc -dl 02 -do 0000 -dt off -e off -fs off ie on -io off -ix off -n -o 29 -p -ql all -qm 0 -qs s2 -qt b -qv 6 -r off -sa 4 -sb epc -sd -sl 00 -so 0000 -st s2 -x <CRLF> OK:<CRLF><CRLF>	none
.rd <CRLF>	CS: .rd<CRLF> EP: 310833B2DDD906C000001234<CRLF> RD: C3993000<CRLF> EP: 341486E37C0000000004254<CRLF> RD: 70CF3000<CRLF> OK:<CRLF><CRLF>	2 transponders read
.rd -dt on -e on <CRLF>	CS: .rd -dt on -e on <CRLF> DT: 2000-01-26T19:00:52<CRLF> EP: 341486E37C0000000004254<CRLF> PC: 3000<CRLF> RD: 70CF3000<CRLF> EP: 310833B2DDD906C000001234<CRLF> PC: 3000<CRLF> RD: C3993000<CRLF> OK: <CRLF><CRLF>	2 transponders read

.rl READ THE LOG FILE

Reads log file, additionally the log file can be deleted or logging can be turned on or off. If the delete option is used the log file is erased and then a new log file is created. This command can only be used in the Autorun file with the –c off option.

Logging can be completely disabled by adding an empty file called “no.log” to the root of the SD card.

Parameters:

-b xxxxxxxx	Read a 512 byte block from the log where xxxxxxxx is an 6 character ASCII hex value representing the block offset from the start of the log file.
-c on/off	turn command logging on or off
-d yes	delete the log file
-l	Read the log file length. Returns a LL response with the log file length in bytes
-n	No action, just set the parameters
-p	List the parameter and their current values
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -d, -c, -l, -p, -n, -b

Parameter defaults

-c on

Valid response field headers:

CS: ER: LB: LE: LL: ME: OK: PR:

Potentially any other response field could be contained in the log file.

Examples:

Command	Response	Action
.rl <CRLF>	CS: .rl<CRLF> LB: Log file data LE: OK: <CRLF> <CRLF>	The log file is read
.rl -d yes <CRLF>	CS: .rl -d yes<CRLF> LB: **** Beginning of Log ****<CRLF> DT: 2000-01-14T20:17:24<CRLF> EV: Log File created<CRLF> LE: **** End of Log ****<CRLF> OK: <CRLF> <CRLF>	The log file is deleted

.sa SWITCH ACTION COMMAND

Defines what happens when the switch is pressed.

Parameters:

-a on/off	Turn asynchronous switch status reporting on or off
-d off/rd/wr/inv/bar/usr/ad	Set the double press switch action
-h on/off	Turn haptic feedback on or off
-p	List the current parameter values
-rd xxx	Sets the delay before the switch double press action is repeated when the switch is held pressed. Where xxx is a value between 1 and 999 ms
-rs xxx	Sets the delay before the switch single press action is repeated when the switch is held pressed. Where xxx is a value between 1 and 999 ms
-s off/rd/wr/inv/bar/usr/ad	Set the single press switch action
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -rd, -rs, -a, -d, -s, -h, -p

Parameter defaults

The parameter defaults are:

-a off, -d ad, -h off, -rd 100, -rs 100, -s ad

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.sa -x <CRLF>	CS: .sa -x<CRLF> OK: <CRLF> <CRLF>	.sa defaults loaded
.sa -p <CRLF>	CS: .sa -p<CRLF> PR: -a off -d ad -h off -p -rd 100 -rs 100 -s ad -x <CRLF> OK:<CRLF><CRLF>	None

.sl SLEEP

This command puts the unit into sleep mode. This will disconnect any active *Bluetooth®* connections.

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: ER: ME: OK:

Examples:

Command	Response	Action
.sl <CRLF>	CS: .sl<CRLF> OK:<CRLF><CRLF>	Unit goes to sleep

.sp USER DEFINED SWITCH SINGLE PRESS ACTION

Reads or sets the single press user action used when “.sa -s usr” is configured.

Parameters:

-s user action command	Set the user action
------------------------	---------------------

Parameter interpretation order

The parameters are interpreted and applied in the following order.

- s

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: ER: ME: OK: SP:

Examples:

Command	Response	Action
.sp <CRLF>	CS: .sp<CRLF> SP: .iv<CRLF> OK: <CRLF> <CRLF>	User action is read
.sp -s .bc -t 4<CRLF>	CS: .sp -s .bc -t 4<CRLF> SP: .bc -t 4<CRLF> OK: <CRLF> <CRLF>	User action is set

.sr SET REGION

If supported by the reader this command reads and/or sets the RF operating region.

Parameters:

-s region code Set the region action

Acceptable region codes are dependent on the version of reader but could include,
us, hk, tw, eu, kr, my, cn, za, br, th, sg, au, in, uy, vn, il, ph, id, nz, jp, pe, ru

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-s

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: ER: ME: OK: SP:

Examples:

Command	Response	Action
.sr <CRLF>	CS: .sr<CRLF> SR: us<CRLF> OK: <CRLF> <CRLF>	Region is United States
.sr -s eu<CRLF>	CS: .sr -s eu<CRLF> SR: eu<CRLF> OK: <CRLF> <CRLF>	Set region to Europe

.ss SWITCH STATE COMMAND

Reads the state of the switch

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: SW: ER: ME: OK:

Examples:

Command	Response	Action
.ss <CRLF>	CS: .ss<CRLF> SW: single <CRLF> OK: <CRLF> <CRLF>	The state of the switch is read and it was on by a single click
.ss <CRLF>	CS: .ss<CRLF> SW: off <CRLF> OK:<CRLF><CRLF>	The state of the switch is read and it was off

.st SLEEP TIMEOUT

Sets the timeout before the reader sleeps if there are no connections to the reader or if no trigger presses occur in HID mode.

Parameters:

-p	List the current parameter values
-hn n=1..999	Sleep duration in seconds for HID
-tn n=15..999	Sleep duration in seconds for no connection
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -h, -t,-p

Parameter defaults

The parameter defaults are:

-h 60 -t 60

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.st -p <CRLF>	CS: .st -p<CRLF> PR: -p -h60 -t60 -x<CRLF> OK: <CRLF> <CRLF>	No Action
.st -t 15<CRLF>	CS: .st -t 15<CRLF> OK: <CRLF> <CRLF>	The no connection sleep timeout is set to 15 Seconds

.tm TIME COMMAND

Reads or sets the time.

Parameters:

-s hhmmss Set the time

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-s

Parameter defaults

No parameter defaults are required:

Valid response field headers:

CS: ER: ME: OK: TM:

Examples:

Command	Response	Action
.tm <CRLF>	CS: .tm<CRLF> TM: 18:24:02<CRLF> OK: <CRLF> <CRLF>	The time is read
.tm -s 203100<CRLF>	CS: .tm -s 203100<CRLF> TM: 20:31:00<CRLF> OK: <CRLF> <CRLF>	The time is set

.ts TRANSPONDER SELECT

This command is used to set the state of transponders. It pushes matching and non-matching transponders into the state determined by the -sa parameter. This command can only be used with persistent target sessions as the carrier will be turned off after the command.

Parameters:

- n No action, just set the parameters
- o nn Output power in dBm, where nn is in the range 10 to 29
- p List the parameter and their current values
- sa n Select action

Parameter n=	Matching Action		Non Matching Action	
	SL Flag	Session Flag	SL Flag	Session Flag
0	assert	Set A	deassert	Set B
1	assert	Set A	nothing	nothing
2	nothing	nothing	deassert	Set B
3	toggle	toggle	nothing	nothing
4	deassert	Set B	assert	Set A
5	deassert	Set B	nothing	nothing
6	nothing	nothing	assert	Set A
7	nothing	nothing	toggle	toggle

- sb epc/tid/usr Bank to use for the select mask
- sd xx..zz Select mask data in 2 character ASCII Hex bytes padded to ensure full bytes, up to a maximum of 32 bytes.
- sl xx Length in bits of the select mask, where xx is a 2 character ASCII Hex value
- so xxxx Number of bits from the start of the block to the start of the select mask, where xxxx is a 4 character ASCII Hex value
- st s1,s2,s3,sl Select target
- x Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order:

-x, -sb, -so, -sl, -sd, -o, -sa, -st, -p, -n

Parameter defaults

The parameter defaults are:

-o 29, -sa 4, -sb epc, -sd, -sl 00, -so 0000, -st s1

Valid response field headers:

CS: ER: ME: OK: PR:

Examples:

Command	Response	Action
.ts -p -n <CRLF>	CS: .ts -p -n<CRLF> PR: -n -o 29 -p -sa 4 -sb epc -sd -sl 00 -so 0000 -st s1 -x <CRLF> OK:<CRLF><CRLF>	none

.vr VERSION INFORMATION COMMAND

Reads the version information from the reader

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: AS: BA: IA: MF: PV: RB: RF: RS: UB: UF: US: ER: ME: OK:

Examples:

Command	Response	Action
.vr <CRLF>	CS: .vr<CRLF> MF: Technology Solutions UK Ltd. <CRLF> US: 1128-EU-000001<CRLF> PV: V2.0.0<CRLF> UF: V3.0.0<CRLF> UB: V1.3.0<CRLF> RS: 1116-ET-000001<CRLF> RF: V2.6.0<CRLF> RB: V1.2.0<CRLF> AS: 1128-S1-EU-000001<CRLF> BA: 00:07:80:41:a4:c6 <CRLF> OK:<CRLF><CRLF>	The version information was read

.wa WRITE COMMAND TO AUTORUN FILE

Writes the following command to the end of the Autorun file. This command cannot be used in the Autorun file.

Parameters:

No parameters are used for this command.

Valid response field headers:

CS: ER: ME: OK:

Examples:

Command	Response	Action
.wa .al -voff -n<CRLF>	CS: .wa .al -voff - n<CRLF> OK: <CRLF> <CRLF>	The “.al -voff -n” command is appended to the the end of the Autorun file, this command is turning off the vibrate at wake up.

.wr WRITE TRANSPONDER COMMAND

This command tries to write data to any transponder that meets the select criteria. It will return an error if no transponder is found.

For each transponder the number of words written follows the WW: response header.

Parameters:

-al on/off	Perform an alert after a successful write using the current alert Parameters from the .al command																																																				
-ap xxxxxxxx	Access password, where xxxxxxxx is an 8 character ASCII Hex value																																																				
-c on/off	Include EPC checksum response																																																				
-da xxxx..zzzz	The data to write in 4 character ASCII Hex words. Up to a maximum of 32 words																																																				
-db epc/tid/usr/res	Data bank to write to																																																				
-dl xx	Length in words of the data to write, where xx is a 2 character ASCII Hex value up to a maximum of 20hex																																																				
-do xxxx	Data bank offset, this is the offset, in 16 bit words, from the start of the block to where the data will be written, where xxxx is a 4 character ASCII Hex value																																																				
-dt on/off	Include date time response																																																				
-e on/off	Include EPC PC information response																																																				
-io on/off	Inventory only, if set to on then no select will be performed before the inventory round phase is started																																																				
-ix on/off	Index number each transponder response																																																				
-n	No action, just set the parameters																																																				
-o nn	Output power in dBm, where nn is in the range 10 to 29																																																				
-p	List the parameter and their current values																																																				
-ql all/nsl/sl	query Select																																																				
-qm n	QT mode n = 0 Standard write n = 1 Write to private memory n = 2 Write to private memory short range n = 3 Write the QT control word with data -da xxxx																																																				
-qs s0,s1,s2,s3	query Session																																																				
-qt a/b	query Target																																																				
-qv nn	Q value (0-15)																																																				
-r on/off	Include transponder RSSI response																																																				
-sa n	Select action																																																				
<table border="1"> <thead> <tr> <th rowspan="2">Parameter</th> <th colspan="2">Matching Action</th> <th colspan="2">Non Matching Action</th> </tr> <tr> <th>n=</th> <th>SL Flag</th> <th>Session Flag</th> <th>SL Flag</th> <th>Session Flag</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>assert</td> <td>Set A</td> <td>deassert</td> <td>Set B</td> </tr> <tr> <td>1</td> <td>assert</td> <td>Set A</td> <td>nothing</td> <td>nothing</td> </tr> <tr> <td>2</td> <td>nothing</td> <td>nothing</td> <td>deassert</td> <td>Set B</td> </tr> <tr> <td>3</td> <td>toggle</td> <td>toggle</td> <td>nothing</td> <td>nothing</td> </tr> <tr> <td>4</td> <td>deassert</td> <td>Set B</td> <td>assert</td> <td>Set A</td> </tr> <tr> <td>5</td> <td>deassert</td> <td>Set B</td> <td>nothing</td> <td>nothing</td> </tr> <tr> <td>6</td> <td>nothing</td> <td>nothing</td> <td>assert</td> <td>Set A</td> </tr> <tr> <td>7</td> <td>nothing</td> <td>nothing</td> <td>toggle</td> <td>toggle</td> </tr> </tbody> </table>				Parameter	Matching Action		Non Matching Action		n=	SL Flag	Session Flag	SL Flag	Session Flag	0	assert	Set A	deassert	Set B	1	assert	Set A	nothing	nothing	2	nothing	nothing	deassert	Set B	3	toggle	toggle	nothing	nothing	4	deassert	Set B	assert	Set A	5	deassert	Set B	nothing	nothing	6	nothing	nothing	assert	Set A	7	nothing	nothing	toggle	toggle
Parameter	Matching Action		Non Matching Action																																																		
	n=	SL Flag	Session Flag	SL Flag	Session Flag																																																
0	assert	Set A	deassert	Set B																																																	
1	assert	Set A	nothing	nothing																																																	
2	nothing	nothing	deassert	Set B																																																	
3	toggle	toggle	nothing	nothing																																																	
4	deassert	Set B	assert	Set A																																																	
5	deassert	Set B	nothing	nothing																																																	
6	nothing	nothing	assert	Set A																																																	
7	nothing	nothing	toggle	toggle																																																	
-sb epc/tid/usr	Bank to use for the select mask																																																				
-sd xx..zz	Select mask data in 2 character ASCII Hex bytes padded to ensure full bytes, up to a maximum of 32 bytes.																																																				
-sl xx	Length in bits of the select mask, where xx is a 2 character ASCII Hex value																																																				
-so xxxx	Number of bits from the start of the block to the start of the select mask, where																																																				

	xxxx is a 4 character ASCII Hex value
-st s0,s1,s2,s3,sl	Select target
-wm s/b	Set the Write Mode to either single or block. Block mode is not supported by all transponders
-wx a/1/2	Impinj Block Write Mode extension. Auto, Force 1 or Force 2 block write. Unless the transponder population is known, use Auto. This option is only valid if -wm=b
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -al, -c, -e, -r, -dt, -qm, -ix, -sb, -so, -sl, -sd, -o, -io, -sa, -st, -ql, -qs, -qt, -qv, -dl, -da, -db, -do, -ap, -wm, -wx, -p, -n

Parameter defaults

The parameter defaults are:

-al on, -ap 00000000, -c off, -da, -db usr, -dl 00, -do 0000, -dt off, -e off, -io off, -ix off, -o 29, -ql all, -qm 0, -qs s2, -qt b, -qv 6, -r off, -sa 4, -sb epc, -sd, -sl 00, -so 0000, -st s2, -wm s, -wx a

Valid response field headers:

CR: CS: DT: EA: EB: EP: ER: IX: ME: OK: PC: PR: RI: WW:

Examples:

Command	Response	Action
.wr -p -n <CRLF>	CS: .wr-p-n<CRLF> PR: -al on -ap 00000000 -c off -da -db usr -dl 00 -do 0000 -dt off -e off -io off -ix off -n -o 29 -p -ql all -qm 0 -qs s2 -qt b -qv 4 -r off -sa 4 -sb epc -sd -sl 00 -so 0000 -st s2 -wm s -wx a -x<CRLF> OK: <CRLF><CRLF>	none
.wr -da1234 -dl01<CRLF>	CS: .wr -da1234 -dl01<CRLF> EP: 310833B2DDD906C000001234<CRLF> WW: 1<CRLF> EP: 310833B2DDD906C000001235<CRLF> WW: 0<CRLF> EP: 310833B2DDD906C000001236<CRLF> WW: 1<CRLF> OK:<CRLF><CRLF>	Write 0x1234 to a transponders

.ws WRITE SINGLE TRANSPONDER COMMAND

This command writes data to a single transponder. It uses a single time slot so there must be enough mask information to select a single transponder.

Returns an error if no transponder is found or if the write is incomplete.

Parameters:

-al on/off	Perform an alert after a successful write using the current alert Parameters from the .al command
-ap xxxxxxxx	Access password, where xxxxxxxx is an 8 character ASCII Hex value
-c on/off	Include EPC checksum response
-da xxxx..zzzz	The data to write in 4 character ASCII Hex words. Up to a maximum of 32 words
-db epc/tid/usr /res	Data bank to write to
-dl xx	Length in words of the data to write, where xx is a 2 character ASCII Hex value up to a maximum of 20hex
-do xxxx	Data bank offset, this is the offset, in 16 bit words, from the start of the block to where the data will be written, where xxxx is a 4 character ASCII Hex value
-dt on/off	Include date time response
-e on/off	Include EPC PC information response
-n	No action, just set the parameters
-o nn	Output power in dBm, where nn is in the range 10 to 29
-p	List the parameter and their current values
-r on/off	Include transponder RSSI response
-sb epc/tid/usr	Bank to use for the select mask
-sd xx..zz	Select mask data in 2 character ASCII Hex bytes padded to ensure full bytes, up to a maximum of 32 bytes.
-sl xx	Length in bits of the select mask, where xx is a 2 character ASCII Hex value
-so xxxx	Number of bits from the start of the block to the start of the select mask, where xxxx is a 4 character ASCII Hex value
-x	Reset the parameters to defaults

Parameter interpretation order

The parameters are interpreted and applied in the following order.

-x, -al, -c, -e, -r, -dt, -sb, -so, -sl, -sd, -o, -dl, -da, -db, -do, -ap, -p, -n

Parameter defaults

The parameter defaults are:

-al on, -ap 00000000, -c off, -da, -db usr, -dl 00, -do 0000, -dt off, -e off, -o 29,
-r off, -sb epc, -sd, -sl 00, -so 0000

Valid response field headers:

CR: CS: DT: EP: ER: ME: OK: PC: PR: RI: WW:

Examples:

Command	Response	Action
.ws -p -n <CRLF>	CS: .ws-p-n<CRLF> PR: -al on -ap 00000000 -c off -da -db usr -dl 00 -do 0000 -dt off -e off -n -o 29 -p -r off -sb epc -sd -sl 00 -so 0000 -x<CRLF> OK: <CRLF><CRLF>	none
.ws -da1234 -dl01<CRLF>	CS: .ws -da1234 -dl01<CRLF> EP: 310833B2DDD906C000001234<CRLF> WW: 1<CRLF> OK:<CRLF><CRLF>	Write 0x1234 to a transponder

HARDWARE SPECIFIC CONNECTION NOTES

For specific information about how to communicate with a particular Technology Solutions UHF reader using the ASCII Protocol please refer to the User Guide for that product. User guides are available for download from the Product Downloads section of each product page (free registration required)

<http://www.tsl.uk.com/products/1119-uhf-rfid-reader-for-the-motorola-mc55-65/>

<http://www.tsl.uk.com/products/1126-desktop-uhf-rfid-reader-with-usb/>

<http://www.tsl.uk.com/products/1128-bluetooth-handheld-uhf-rfid-reader/>

The core of the ASCII protocol is based on reading and writing serial data over a serial connection. Typically this connection is 115200 baud, 8 data bits, 1 stop bit and no parity with CTS/RTS (hardware) handshaking. Although some products use a standard serial port those that communicate over USB and *Bluetooth*[®] use a virtual serial port.

When communicating via *Bluetooth*[®] you can either use a *Bluetooth*[®] virtual serial port and have your application open a com port using serial APIs or alternatively you can usually open a *Bluetooth*[®] stream using the Serial Port Profile service identifier without having to use a serial port layer. Refer to the samples provided with the SDKs or contact support@tsl.uk.com for more information.

ABOUT TSL

ABOUT

TSL designs and manufactures both standard and custom embedded, snap on and standalone peripherals for handheld computer terminals. Embedded technologies include:

- RFID - Low Frequency, High Frequency & UHF
- *Bluetooth®* wireless technology
- Contact Smartcard
- Fingerprint Biometrics
- 1D and 2D Barcode Scanning
- Magnetic Card Readers
- OCR-B and ePassport

Utilizing class leading Industrial design, TSL develops products from concept through to high volume manufacture for Blue Chip companies around the world. Using the above technologies TSL develops innovative products in a timely and cost effective manner for a broad range of handheld devices.

CONTACT

Address:	Technology Solutions (UK) Limited, Suite A, Loughborough Technology Centre, Epinal Way, Loughborough, Leicestershire, LE11 3GE. United Kingdom.
Telephone:	+44 1509 238248
Fax:	+44 1509 214144
Email:	enquiries@tsl.com
Website:	www.tsl.com



ISO 9001: 2008

© Technology Solutions (UK) Ltd 2017. All rights reserved. Technology Solutions (UK) Limited reserves the right to change its products, specifications and services at any time without notice.